

# Pacific Products and Services




## Square post slip base

The **Square Post Break-Out™** Coupler provides significant additional benefits to existing square post systems. Put simply you won't be replacing anchors and may reuse the top sign post.

Incorporating the patented Tri-Circular engineered 360° shear section, it will breakaway at 90% of the post strength when impacted from any angle or height even direct wheel, plow or undercarriage hits will not affect the post anchor with Break-Out™ .

The Square Break-Out will withstand high wind loads without weakening and is intended to be used on all post sizes from 1-3/4" through to 2-1/2" as a simple effective alternative to slip bases and conventional installations in soil or concrete.

- Fasteners and fastener torque level have no effect on Breakaway feature which is preset, and does not incorporate shear pins
- Three (3) main parts ensure reliable real world usability
- Breaks flush with grade (plugs hole) which prevents undercarriage or plow/mower damage as well as pedestrian trip-fall incidents
- Can be attached to existing standard 2-1/4" square anchors or used with the Sign Supports Modular Anchor System
- Wedge-Lock™ feature applies enormous force to lock the coupler inside the anchor
- Knocked down posts can be repaired with simple hand tools in minutes eliminating post pullers drivers or saws



# Pacific Products and Services

## Common Ordering Information

Part Number	Description	Wt. lbs.	Pack	Ext. lbs.	Remarks
BOR238-1316	2-3/8" Rd. Coupler	5.0	16	80.0	Use on 13-16 Ga. Round Post
BOR238-1316C	2-3/8" Rd. Coupler Top	4.0	16	64.0	
BOR238-1012	2-3/8" Rd. Coupler	5.0	16	80.0	Use on 10-12 Ga. Round Post
BOR238-1012C	2-3/8" Rd. Coupler Top	4.0	16	64.0	
BOS134-14	1-3/4" Sq. Coupler	4.5	16	72.0	Use on 1-3/4" 14 Ga. Square Post
BOS134-14C	1-3/4" Sq. Coupler Top	3.5	16	56.0	
BOS134-12	1-3/4" Sq. Coupler	4.5	16	72.0	Use on 1-3/4" 12 Ga. Square Post
BOS134-12C	1-3/4" Sq. Coupler Top	3.5	16	56.0	
BOS200-14	2-0/0" Sq. Coupler	5.0	16	80.0	Use on 2-0/0" 14 Ga. Square Post
BOS200-14C	2-0/0" Sq. Coupler Top	4.0	16	64.0	
BOS200-12	2-0/0" Sq. Coupler	5.0	16	80.0	Use on 2-0/0" 12 Ga. Square Post
BOS200-12C	2-0/0" Sq. Coupler Top	4.0	16	64.0	
BOS214-14	2-1/4" Sq. Coupler	5.5	16	88.0	Use on 2-1/4" 14 Ga. Square Post
BOS214C	2-1/4" Sq. Coupler Top	4.5	16	72.0	
BOS214-12	2-1/4" Sq. Coupler	5.5	16	88.0	Use on 2-1/4" 12 Ga. Square Post
BOS214-12C	2-1/4" Sq. Coupler Top	4.5	16	72.0	
BOS212-12	2-1/2" Sq. Coupler	6.0	16	96.0	Use on 2-1/2" 12 Ga. Square Post
BOS212-12C	2-1/2" Sq. Coupler Top	5.0	16	80.0	
BOU200	2 Lb. U Coupler	5.0	16	80.0	Use on 2 and 2.5 Lb. U Post
BOU200C	2 Lb. U Coupler Top	4.0	16	64.0	
BOU300	3 Lb. U Coupler	5.5	16	88.0	Use on 3 Lb. U Post
BOU300C	3 Lb. U Coupler Top	4.5	16	72.0	
BOS134W	1-3/4" Wedge	1.0	16	16.0	Use with BOS134-14 and 12
BOS200W	2-0/0" Wedge	1.0	16	16.0	Use with BOS200-14 and 12
B1	Center Bolt	0.3	16	4.8	Use with all Couplers
SG-1/8-CC	Seal Washer	0.1	16	1.6	Use with all Couplers
HDA A 200	Anchor Adapter 2-0/0"	5.6	8	45.0	Use in concrete
HDA A 134	Anchor Adapter 1-3/4"	5.6	8	45.0	Use in concrete
HDE12	Anchor Extension 12"	2.0	8	16.0	Use in concrete (16" OAL w/ HDA A)
HDE20	Anchor Extension 20"	4.0	8	32.0	Use in asphalt or soil (24" OAL w/ HDA A)
HDE26	Anchor Extension 26"	6.0	8	48.0	Use in soil (30" OAL w/ HDA A)
HDS212	Anchor Stabilizer	4.0	8	32.0	Use with soil extension
G23E	Power post driver	49.5	1	49.5	4 Cycle
DC102-T	U-Channel Driver 2-4 lb.	15	1	15	Specify Shank size
DP212-T	2-1/2" Rd. Pipe Driver	12	1	12	Specify Shank size
DP238-T	Delineator Driver	12	1	12	Specify Shank size
DS134-T	1-3/4" Sq. Tube Driver	12	1	12	Specify Shank size
DS200-T	2-0/0" Sq. Tube Driver	12	1	12	Specify Shank size
DS214-T	2-1/4" Sq. Tube Driver	12	1	12	Specify Shank size
DS212-T	2-1/2" Sq. Tube Driver	12	1	12	Specify Shank size

Distributed by:  
Pacific Products and Services, llc  
7323 Lynwood Way  
Highland CA. 92346  
909.633.1180